

Designed to supplement the Molnar Hoist Four Post Hoist range, these lifting aids will improve workshop efficiency and safety

FOUR POST ACCESSORIES

**M
O
L
N
A
R**



HOISTS

**DRAFT
4APR11
07**

JB11 & JB11A



'AIR JACKING BEAM'

Raise a vehicle for wheel free service options

JB11A
Wide version for 'A' series

Refer Air Jacking Beam Accessories brochure for related accessories

	JB11	JB11A
Width	1100 mm	1200 mm
Max span	1275 mm	<
Min height (above platform)	75 mm	<
Max height (above platform)	310 mm	<

7252-023-01 & 7252-023-01 A



'JACK STAND'

Insert between platforms; can be turned upside down and used as a tool tray

7252-023-01 A
Wide version for 'A' series

	7252-023-01	7252-023-01 A
Length	1045 mm	1145 mm
Width	225 mm	<
Height	60 mm	<

4488-S/W-66



'FOUR POST RUN-UPS, SHORT'

Run-up (single) for workshops where space is an issue

Length	815 mm
Width	500 mm

4488-S/W-66EL



'FOUR POST RUN-UPS, LONG'

Additional run-up (single) to create 'drive-through' capability

Length	1190 mm
Width	500 mm

LBJ-04



'SLIP PLATES'

Slip Plates (pair) for vehicles with independent rear suspension

Length	1500 mm
Width	500 mm

Refer Slip Plate brochure for more details

As the policy of Molnar Hoists is one of continuous improvement, the manufacturer reserves the right to change specifications without notice.